

Instructions how to Tie!

* please read the instructions carefully and assembles them.

* Important instructions are marked with red circles.



Dial x2
shoelaces x2
One hook



Assembly
guide
video

1

TIP!
The hook makes it easier to insert the wire into the shoe.

check

(From the LEFT side)

Start lacing from the bottom holes
Thread the wire through the bottom eyelets from underneath, like normal shoelaces.

*** Both wires should be threaded to face left on the left shoe and right on the right shoe**

2

Press the dial until you hear a "Tick."

*** Make sure to turn the dial until the red marks match the exact same shape.**

3

Place the top line up and the bottom line down, aligned in the center as shown.

3-1

Insert each shoelace into the inner holes one by one

4

Insert all the laces through the opposite holes from the inside to the outside.

5

Insert the shoelaces one by one from bottom to top, as shown in the picture.

6

Turn the dial once until the back side is visible, so that one side of the lace wraps around the line as shown in the picture.

7

Tie a basic knot around the hole twice, leaving about 1cm of lace at the end.

8

Pull the lace to move the knot near the dial. Then pull the other lace so the dial faces outward.

8-1

Turn the dial to tighten. Repeat for the other shoe—done!